









RSW



RUN AT LEAST (6) WIRES FROM MASTER-SLAVE (MIN. 22 GA.) FOR CONTROL

WARNING

TURN POWER OFF BEFORE MAKING ANY CONNECTIONS!
CONNECT ALL CONTROLS TO MASTER!



*: SEE NOTES ON ACCESSORIES PAGE