



- NOTES:
- 1. WIRE IS NOT USED WHEN EXTERNAL INTERLOCK OR STOP BUTTON IS USED.
 - A- TREADLES, PULL SWITCHES, KEY SWITCHES, WANDS, PHOTO-ELECTRIC DEVICES, ETC. MAY BE CONNECTED TO TERMINALS INDICATED.
 - B- REMOTE CONTROL UNITS (EXCLUDING TREADLES AND PHOTO-ELECTRIC UNITS), PULL SWITCHES AND SINGLE CONTACT CONTROL STATIONS, MAY BE CONNECTED TO TERMINALS INDICATED.

TERMINALS # 3 AND # 4 PROVIDE 24 VAC FOR ACCESSORIES.
WARNING DO NOT SHORT TERMINALS # 3 AND # 4.

PowerMaster	
WIRING TYPE: MSW SWING GATE OPERATOR	
MTR/CNTR: 1 Ø	
DATE: 9-91	REV: 10 1-92
BY: F.S.	
SPECIAL: TIMER TO CLOSE IN DASHED LINES FOR MODEL MSW SINGLE, MASTER/SLAVE	
WIRING DIAGRAM NO. MS-31 MRT	
© Copyright PowerMaster 1997 No portion of this diagram may be reproduced without the expressed written permission of the manufacturer.	