



NOTES:
 1-WIRE-NOT FURNISHED WHEN EXTERNAL INT'L'K SWITCH IS USED.
 - NOT FURNISHED WHEN STOP BUTTON IS USED.
 2-WIRE-NOT FURNISHED WHEN TIMER DEFEAT SWITCH IS USE
 3- FOR MOMENTARY CLOSE MOVE RED WIRE TO TERMINAL #5.
 A-TREADLES,PULL SWITCHES, KEY SWITCHES, PHOTO-ELECTRIC DEVICES,
 ECT. MAY BE CONNECTED TO TERMINALS INDICATED
 B-REMOTE CONTROL UNITS (EXCLUDING TREADLES AND PHOTO-ELECTRIC
 UNITS). PULL SWITCHES AND SINGLE CONTACT CONTROL STATIONS,
 MAY BE CONNECTED TO TERMINALS INDICATED.

2-WIRE EDGE OR AIRSWITCH
 OBSTRUCTION SENSING DEVICE

PowerMaster	
WIRING TYP: SAFETY EDGE 1 Ø	
REV. W/OPTIONAL TIMER	
MTR/CNTR: 1 Ø	
DATE: 1-15-97	REV. 10
BY: F.S.	
SPECIAL: OPTIONAL TIMER CIRCUIT IN DASHED LINES. DELAY ON REVERSE	
WIRING DIAGRAM 1331-2	
© Copyright PowerMaster 1997 No portion of this diagram may be reproduced without the expressed written permission of the manufacturer.	