



RSG-550D WIRING DIAGRAM FOR: SINGLE OR MASTER/SLAVE DIAGRAM RSG-SSB-2D

NOTE:

- (1) Operators are shipped as right-hand units.
To wire for left-hand operation, reverse red and blue motor wires at capacitors.
- (2) On slave units, remove yellow jumper from #4 to #5 and blue jumper from #2 to #3.
- (3) On left hand units reverse yellow & blue wires on limit switches.
- (4) On left hand units move R/Y wire to opposite limit switch as shown.

CAUTION: Make sure power is off before making any adjustments.