


RSG 550



RSG 550 WIRING DIAGRAM FOR: SINGLE

NOTE:

- (1) Operators are shipped as right-hand units.
To wire for left-hand operation, reverse red and blue motor wires at capacitor.
- (2) On left hand units reverse wires on limit switches.

CAUTION: Make sure power is off before making any adjustments.