



NOTE:

- 1 - WIRE IS NOT USED WHEN EXTERNAL INTERLOCK SWITCH OR STOP BUTTON IS USED.
- 2 - TIMER DEPART SWITCH, WHEN USED, CONNECTS ACROSS TERMINALS 10 & 19. CLOSING SWITCH DISABLES TIMER.

A - TREADLES, PULL SWITCHES, KEY SWITCHES, WANDS, PHOTO-ELECTRIC DEVICES, ETC. MAY BE CONNECTED TO TERMINALS INDICATED.

B - REMOTE CONTROL UNITS (EXCLUDING TREADLES AND PHOTO-ELECTRIC UNITS), PULL SWITCHES AND SINGLE CONTACT CONTROL STATIONS, MAY BE CONNECTED TO TERMINALS INDICATED.

TERMINALS #3 & #4 PROVIDE 24 VAC FOR ACCESSORIES

COMMERCIAL SWING GATE OPERATOR	
MTR/CNTR: 1Ø	
DATE: 4-27-82	REV 10 1-92
BY: R.L.	Dr. by: J.D.
OPTIONAL: TIMER TO CLOSE IN DASHED LINES	
WIRING DIAGRAM NO. 331-1/R-MR1	
FOR MODEL SG1, SG, BSG, SINGLE, MASTER/SLAVE.	

WIRED FOR:
V - 1Ø