



▲ REMOVE JUMPER WHEN USED.

NOTE: "QUICK CLOSE" INPUT WILL STOP GATE DURING OPEN CYCLE AND CAUSE IT TO CLOSE WHEN "QUICK CLOSE" IS USED. CLOSE SAFETY IS DISABLED WHEN CLOSE CYCLE STARTS, "OPEN" DEVICE WILL REVERSE GATE TO FULL OPEN.

Ⓐ REMOVE IF STOP BUTTON OR INTERLOCK IS USED.

*CLOSE WARNING RELAY CONTACTS ACTIVE WHENEVER GATE IS CLOSING. CONTACTS RATED @ 5A, 250 VAC.

PowerMaster	
MODEL P1500 AND P5000 BARCON-1 CONTROL BOARD	
DATE: 2/8/02	REV. 2
BY: F.S.	R.P.L.
SPECIAL:	
WIRING DIAGRAM 5664	
© Copyright PowerMaster 1997 No portion of this diagram may be reproduced without the expressed written permission of the manufacturer.	